

INSTALLATION INSTRUCTIONS

PJ6000

D-RING SHACKLE MOUNTS



Package contents:

- 2) PJ6000 D-Ring Shackle Mount Plates
- 1) Hardware kit consisting of the following:
 - 8) 1/2-13 x 3 button head cap screws
 - 8) 1/2 flat washers
 - 8) 1/2-13 nuts

- 1) Installation Instruction sheet

UNPACK YOUR BUMPER AND CHECK THE PACKAGE CONTENTS AGAINST THE ABOVE LIST. If you do not have all the parts listed below, call 661-304-0360.

DISCLAIMER

PUREJEEP has made every effort to provide correct information. Each item has been fit checked for accuracy. PUREJEEP reserves the right to alter, make changes or replace part numbers and descriptions without notice. PUREJEEP will not be held responsible for changes or misprints or manufacturing changes made by the vehicle manufacturer. For questions regarding PUREJEEP components call our Technical Support Department at 661-304-0306

BEGIN THE INSTALLATION

PUREJEEP FRONT BUMPERS

Step 1A (No Photo)

If you are installing your PUREJEEP D-ring shackle mounts at the same time as your PUREJEEP front bumper, refer to the installation instructions for your bumper. Be sure to use the 3-inch bolts provide in this kit.

STEP 1B (No Photo)

If you are installing your PUREJEEP D-ring shackle mounts, on an existing PUREJEEP front bumper remove the lower outer bolt from each side of your bumper.

STEP 2 (No Photo)

Looking at the backside of your D-ring shackle mount plates, you will see a mark. This mark indicates the top side of the bolt-hole pattern. The D-ring shackle mount plate holes are wider at the top to accommodate the factory JK front mounting flange bolt pattern. Install one of the new 3-inch long bolts thru the lower outer hole in the D-ring shackle mount plate on each side. Caution, if the plates are not mounted with the mark on the top, you will not be able to install all the bolts. Let the D-ring shackle mount

plate hang of the bolt and tighten the nut hand tight, but loose enough that the plate can be rotated by hand.

STEP 3 (No Photo)

You will now remove the upper outer bumper bolts, one at a time and install them into the holes in the bumper face from the back side so that the threads come thru the bumper face. The spacer plates behind the bumper are now secure and should not fall out during the installation of your PUREJEEP D-ring shackle mount plates.

STEP 4 (No Photo)

Remove all remaining bumper bolts and pull the one bolt on each side that is facing forward back so that it is flush with the bumper face. Next, rotate the D-ring shackle mount plate and install the 3-inch bolts from the hardware kit into the holes. The final step is to push out the rearward facing bolts used for setup with the 3-inch bolts from the hardware kit.

STEP 5 (No Photo)

Tighten all the bolts and your D-ring Shackle mount front installation is now complete.

NOTE: The 3-inch bolts provide in this kit MUST be use for the front installation.

BEGIN THE INSTALLATION

PUREJEEP REAR BUMPERS

Step 1A (No Photo)

If you are installing your PUREJEEP D-ring shackle mounts at the same time as your PUREJEEP rear bumper, refer to the installation instructions for your bumper

STEP 1B (No Photo)

If you are installing your PUREJEEP D-ring shackle mounts, on an existing PUREJEEP front bumper remove the existing bolts in the bumper face.

STEP 2 (No Photo)

Looking at the backside of your D-ring shackle mount plates, you will see a mark. This mark indicates the top side of the bolt-hole pattern. The D-ring shackle mount plate holes are wider at the top to accommodate the factory JK front mounting flange bolt pattern. This same patten is reproduced in the PUREJEEP rear bumper face. Caution, if the plates are not mounted with the mark on the top, you will not be able to install all the bolts.

STEP 3 (No Photo)

Install the D-ring shackle mount plates on your PRUEJEEP rear bumper. Tighten all the bolts and your D-ring Shackle mount rear installation is now complete.

