

HANSON OFFROAD

12539 Jomani Drive Bakersfield, CA 93312
P:877.757.9779 sales@hansonoffroad.com

CU53-P U-PLATFORM INSTALLATION

ALSO COVERS: JC2 CARGO, JC5 CARGO, & CLB53LR INSTALLATION

This Hanson basket assembly will use the large U-platform and also our L-bracket kit to complete the installation.

Drilling is required through the Square Frame Tire Carrier as listed below.

NOTE: 3M foam tape and aluminum pop rivets are included to mount the aluminum floor to the base of the basket. The foam tape reduces rattle and the rivets secure the floor for daily driving. Customer will need to drill the necessary holes to install rivets.



1. Using the supplied L-brackets and hardware, bolt the upper mount to the tire carrier as shown in the photo to the left.



2. With the upper bolt snug, align the lower mount as shown in the photo to the right and drill through the lower portion of the tire carrier for a 3/8" bolt.

3. Complete installation of the L-brackets on the opposite side.

4. With the L-brackets snugly in place, drop the U-platform on the L-brackets and align the mounting holes underneath and secure using supplied hardware.

5. NOTE: IT IS RECOMMENDED TO KEEP HARDWARE SOMEWHAT LOOSE TO ALLOW FOR THE BASKET TO BE INSTALLED. ONCE ALL BOLTS ARE IN THEIR RESPECTIVE POSITIONS, THEY CAN BE TIGHTENED TO 20FT/LBS.

