



6951 McDivitt Drive Bakersfield, CA 93313

P:877.757.9779 sales@purejeep.com

<http://www.purejeep.com>

PJ1080: JK RUBICON ELECTRONIC SWAY-BAR SKIDPLATE INSTALLATION INSTRUCTIONS



- 1- Sway Bar Skid
- 2 - 5/16" x 2" Clamps
- 4 - 5/16" Flat Washer
- 4 - 5/16 Nylock Nut
- 3 - 1/2" x 1.5" Bolt
- 6 - 1/2" SAE Flat Washer
- 3 - 1/2" Stover Nut



Our skid for the electronic sway-bar found on the Rubicon JK models can be installed with (as shown) or without aftermarket front skid plates. Drilling is required in the stock under-rider support to properly mount. On some early model JKs, 1 of the necessary holes will be present. On most applications, all 3 holes will need to be drilled.

1. Begin by placing the skid under the sway bar motor as shown in the above photo. Locate the round tube just rear of the sway bar motor. Loosely install the supplied 2" u-bolts to pull the skid into place. With the skid snug in place, align the 3 holes along the under-rider bar.
2. Using a center punch or scribe, mark the center of each of the 3 holes and drill out to pass a 1/2" bolt. Once drilled, install the supplied 1/2" bolts and tighten. With these bolts tight, completely secure the u-bolts to the upper tube.