



# PUREJEEP - PJ4011

## TJ STEEL BEDSIDES

### STANDARD-STRETCH / FLAT-TUBE FENDER

NOTE: These instructions cover the installation of all PUREJEEP steel bedsides. This includes the standard flat-style, steel tube fender, stretch flat-style and also stretch tube fender. We recommend the help of a friend to assist in positioning of the beside on the Wrangler for optimum fit.

1 - Driver Side Bedside w/Tube fender	16 - 1/4" Stover Nut	6 - 1/4" Flat Washer
1 - Pass. Side Bedside w/Tube Fender	15 - 1/4" Nutzerts	1 - Nutzert Install Tool
30 - 1/4" x 3/4" Bolt	15 - 1/4" Fender Washers	

1. Installation for each bedside is similar. The driver side will involve the removal and re-installation of the gas filler cover. Once removed, clamp the bedside to the driver's side the Jeep and mark each hole. Each hole will need to be drilled out using a 1/4" drill bit. Install the supplied nut-zerts using the included tool where the 3/4" bolt will not pass and allow a washer and nut to be installed. Repeat clamp, transfer, and drill procedure for the passenger side and complete installation.



**PUREJEEP TECH LINE: 661-847-0188**



**PUREJEEP TECH LINE: 661-847-0188**